

Trim, Inc. Fuse Panel Cheat Sheet

Questions to Ask

1) How Many Amps Per Position?

2) What is the highest amperage fuse you need?

Amperage	Fuse Rating Coverage							
	GMT	TPM	KLM	TPA	TPS	TLS	TPC	TPW
1/10A			0300268431					
1/8A			0300268432					
15/100A								
18/100A	0300097000							
1/5A			0300268433					
1/4A	0300097001		0300268434					
3/10A			0300268435					
3/8A	0300097016							
1/2A	0300097002		0300268436					
65/100A	0300097065							
3/4A	0300097003		0300268437					
1A	0300097004		0300268401		0300350001	0300390001		
1-1/3A	0300097005							
1-1/2A	0300097006		0300268438					
2A	0300097007		0300268402		0300350002			
2-1/2A								
3A	0300097008	7500192703	0300268403	7500192003	0300350003	0300390003	0300360003	
3-1/2A	0300097013							
4A	0300097012	7500192704	0300268404				0300360004	
5A	0300097009	7500192705	0300268405	7500192005	0300350005	0300390005	0300360005	
6A		7500192706	0300268406		0300350006	0300390006	0300360006	
7A		7500192707					0300360007	
7-1/2A	0300097011							
8A		7500192708	0300268408				0300360008	
9A								
10A	0300097010	7500192710	0300268410	7500192010	0300350010	0300390010	0300360010	
12A	0300097014	7500192712					0300360012	
15A	0300097015	7500192715	0300268415	7500192015	0300350015	0300390015	0300360015	
20A	0300097320*	7500192720	0300268420	7500192020	0300350020	0300390020	0300360020	
25A		7500192725	0300268425	7500192025	0300350025	0300390025	0300360025	
30A		7500192730	0300268430	7500192030	0300350030	0300390030	0300360030	
35A					0300350035	0300390035		
40A				7500192040	0300350040	0300390040	0300360040	
50A				7500192050	0300350050	0300390050	0300360050	
60A					0300350060	0300390060	0300360060	
70A					0300350070	0300390070		
75A							0300360075	
80A						0300390080		
90A						0300390090	0300360090	
100A						0300390100	0300360100	
125A						0300390125	0300360125	
150A								0300380150
175A								0300380175
200A								0300380200
225A								0300380225
250A								0300380250

Fuse Panels Families To Choose for the Fuses*

GMT	GMT Fuse Panels Optimum Value, 15A per position, Total Front Access
TPM	TPM Panels - 30A per position, GMT TPM Panels 30A per position
KLM	KLM Fuse Panels 30A per position, GMT KLM Fuse Panels 30A per position
TPA	TPA Fuse Panels 50A per position, GMT TPA Fuse Panels 50A per position
TPS	High Current Power Distribution Unit 125A per position
TLS	High Current Power Distribution Unit 125A per position
TPC	High Current Power Distribution Unit 125A per position
TPW	High Current Power Distribution Unit 125A per position

*For specific part numbers or help please call us at 800-298-7466 or visit our website

www.triminc.com!